

FOLDABar Corner Assembly



1 - Fit corner top support brackets



2 - Fit cap-head screws at base level



3 - Push FOLDABar units together



4 - Sit base level infill in position



4 - Sit angled top in position



6 - Secure with pull-down clamps



7 - Slide IriBond corner panel into position



8 - Fit Corner Trims